

10/3/07, 4:15 PM CST

FootPrints Based Test Cases

Issue Number	134		
Issue Title	Ability to convert non-TSS link to TSS link		
Description	The ability to assign a detector to a non-TSS link (thereby converting it to a TSS link) would be helpful for us in the future. It would not be a highly used feature, as its only valuable during configuration. However, if it is not a costly enhancement to make, it should be considered for future SunGuide releases.		
Resolution	In the upcoming 3.0 release, all existing TSS and non-TSS links will be updated to a single set of links maintained by TSS, whether fed by detector data or not. If a detector is mapped, and an existing link name is used, the mapping should automatically link together. I believe this functionality will accomplish what you're wanting to see. I'll close the issue for now, and once 3.0 hits and your links are updated, please file a bug report if you are unable to map an existing, unmapped link to a detector. (Note that this matching will be done strictly on the name of the link. Even a one character difference, change in capitalization, etc. will cause it to fail to match.)		
Test Steps		Result	
		P	F
Steps for TSS Remapping: Using the TSS Link/Shield editor, place a new unmapped link on the map. Note the name of the link created. Save the map and exit the editor. Load the Operator Map. View the newly added link and verify it is not associated with any TSS detector. Exit the Operator Map. Using the Admin Editor, add a new mapped link, using the same name as noted previously. Create a number of lanes for the link. Save the mapping and exit the editor. Restart TSS to cause the simulated data to begin propogating data to the new link. Load the Operator Map. View the link and verify it is now associated with the TSS link and is reporting data.		<input checked="" type="checkbox"/>	<input type="checkbox"/>

Trey Falkender
x Brent Beal

10/3/07, 4:25 PM CST

Issue Number	225	
Issue Title	SAS Subsystem Requires Restart	
Description	While SwRI was troubleshooting SAS in District 6, it was noticed every time the CCTV Subsystem was restarted, SAS would stop the Schedules on all cameras. SAS Subsystem had to be restarted for the Schedules work. SwRI is aware of issue and will provide a fix when resolved.	
Resolution		
	Test Steps	Result
		P F
	Start SAS schedule and verify that it is running on appropriate camera(s).	<input checked="" type="checkbox"/> <input type="checkbox"/>
	Stop CCTV subsystem.	
	Verify that the SAS schedule has stopped running on the camera(s).	
	Restart the CCTV subsystem.	
	Verify that the SAS schedule resumes upon CCTV startup.	

*Tracy Tillander
f. Hunt Ben*

Issue Number	254	
Issue Title	Refresh Geometry button on Video Wall Control Dialog not working	
Description	See screenshots comparing the Barco Application dialog and the SunGuide Video Wall Control after pressing Refresh Geometry button	
Resolution	The issue has been addressed by 3.0. However, we will wait until field verification after 3.0 to close the issue.	
	Test Steps	Result
		P F
	This test has not been repeatable in the lab.	<input type="checkbox"/> <input type="checkbox"/>
		<input type="checkbox"/> <input type="checkbox"/>
		<input type="checkbox"/> <input type="checkbox"/>

Issue Number	258	
Issue Title	preferences lost	
Description	<p>Reference Issue 97 for past occurrences. This issue does still occur. It does not occur frequently. It does occur at times where we do not know of any other issues. Such was the case last Wednesday July 11th around 8:30am. Restarting the Preference Manager is a work around for this problem.</p> <p>Summary: Preferences stored by the operators appear to be lost. This occurs at the same time for all operators. Its difficult to determine the exact time this occurs as its only noticed when the operator logs into the system. Someone at SwRI had inquired if restarting Preference Manager restores the lost preferences, and it does.</p>	
Resolution	<p>We updated the GUI Preference Manager locally to attempt to retry the database request in the event the error we detected was encountered again. Since that time, the problem has not been recreated. We'll include the revision in the 3.0 release, and revisit the issue at that time. If you see this behavior again after 3.0 is installed, please let us know.</p>	
Test Steps		Result
		P
		F
Not testable – SwRI cannot recreate.		<input type="checkbox"/>
		<input type="checkbox"/>

10/3/07, 4:35 PM EST

Issue Number	295								
Issue Title	TvT needs to be restarted for new template								
Description	During SICIP ad hoc testing, a new message template, destination, and updated device template were created. The new template did not display correctly until TVT was restarted. Before the restart, a version of the message without any free text was generated instead.								
Resolution									
	<table border="1"><thead><tr><th rowspan="2">Test Steps</th><th colspan="2">Result</th></tr><tr><th>P</th><th>F</th></tr></thead><tbody><tr><td>Steps for using new TVT template: Choose device that has TVT message generation enabled. Load the Operator Map and examine the currently posted TVT message for that device by viewing the appropriate MAS queue. Create new TVT message template in Admin Editor. Create new TVT destination template in Admin Editor. Open device template for examined device in Admin Editor. Modify device template to use newly created message template and destination. Verify that the new device template is applied to the test device queue by TVT, without restarting the TVT subsystem.</td><td><input type="checkbox"/></td><td><input checked="" type="checkbox"/></td></tr></tbody></table>	Test Steps	Result		P	F	Steps for using new TVT template: Choose device that has TVT message generation enabled. Load the Operator Map and examine the currently posted TVT message for that device by viewing the appropriate MAS queue. Create new TVT message template in Admin Editor. Create new TVT destination template in Admin Editor. Open device template for examined device in Admin Editor. Modify device template to use newly created message template and destination. Verify that the new device template is applied to the test device queue by TVT, without restarting the TVT subsystem.	<input type="checkbox"/>	<input checked="" type="checkbox"/>
Test Steps	Result								
	P	F							
Steps for using new TVT template: Choose device that has TVT message generation enabled. Load the Operator Map and examine the currently posted TVT message for that device by viewing the appropriate MAS queue. Create new TVT message template in Admin Editor. Create new TVT destination template in Admin Editor. Open device template for examined device in Admin Editor. Modify device template to use newly created message template and destination. Verify that the new device template is applied to the test device queue by TVT, without restarting the TVT subsystem.	<input type="checkbox"/>	<input checked="" type="checkbox"/>							

TVT message not displaying.

Ray Gillander
Brent Beer